



Vehicle Identification

SPECTRE Access, ATX & ATX4 UHF RFID reader





SOMMAIRE

SOMMAIRE.....	1
1- General principles of UHF technoly	3
1.1 How it works.....	3
1.2 Uses and limitations, environmental effects, tips	3
1.3 Optimal orientation	4
1.4 Installations: the basic rules	5
1.5 Positioning the tags	6
1.6 Athermic windshields	8
2- SPECTRE range	9
ANT_SPECTRE-A/B.....	9
SMA	9
SLA	9
CAB_SPECTRE	10
ANT_SPECTRE-E/F	11
ATX4.....	11
ATX.....	11
CAB-ATEX.....	12
3- Hybrid UHF SPECTRE and URx installation	12
3.1 Powers	13
3.1.1 Table of URD powers.....	13
3.1.2 Table of URC2 powers.....	14
3.2 Details of the connector	15
3.3 Hybrid system with a URD or URC2 reader	16
3.4 Hybrid system with a SPECTRE reader.....	18
4- RSSI FILTERING	21
4.1 Introduction.....	21
4.2 Exemple	21
5- Input / output parameters	23
5.1 Introduction.....	23
5.2 Inputs.....	24



- 5.3 Examples of input use 25
 - 5.3.1 Reading activated when the presence of a vehicle is detected with detector OPTEX 25
 - 5.3.2 Reading activated when the presence of a vehicle is detected with ground loop 27
- 5.4 Outputs 28
 - 5.4.1 PULL UP TO V+ 28
 - 5.4.2 Open drain 30
- 5.5 Examples of output use 33
 - 5.5.1 Activation of an external optical warning 33
 - 5.5.2 Control of an external relay 34
- 6- Approach to projects 35
- 7- Examples of configurations 36
 - 7.1 One-lane single access 36
 - 7.2 One-lane single access – Double height 37
 - 7.3 Single Entrance / Exit for light vehicles only with a central island 38
 - 7.4 Double-width access on a two-way public road 39
 - 7.5 Multiple-lane access 40
- 8- Installation methodology 41
- 9- Athermic windshields 42
- 10- Radiation pattern ANT-SPECTRE 43
 - 10-1 Lower band – Horizontal polarization; 867 MHz 43
 - 10-2 Lower band – Vertical polarization; 867 MHz 44
 - 10-3 Upper band - Horizontal polarization; 915 MHz 45
 - 10-4 Upper band - Vertical polarization; 915 MHz 46
- 11- Radiation pattern integrated antenna ATX 47
 - 11-1 Lower band – Horizontal polarization; 867 MHz 47
 - 11-2 Lower band – Vertical polarization; 867 MHz 48
 - 11-3 Upper band - Horizontal polarization; 915 MHz 49
 - 11-4 Upper band - Vertical polarization; 915 MHz 50
- 12- FAQ 51
- 13- VERSION 52



1- General principles of UHF technology

1.1 How it works

Passive RFID applications are authorized in the range from 860 MHz to 960 MHz. The precise limits vary from one country to another. The two main frequency bands are 865-868 MHz and 902-928 MHz.

Depending on the power of the reader, the gain and the directivity of its antenna, and the characteristics of the tag to be read, the actual range of a passive UHF RFID system can extend from about 10 centimeters to about 10 meters..

1.2 Uses and limitations, environmental effects, tips

Certain physical rules apply to this technology that can influence operation and performance in terms of distance and speed.


The following salient points should be kept in mind.

- The influence of the materials on which or behind which the tag is used.
Tags must be adapted to their environment in order to produce the best results.
- At this frequency, waves do not pass through liquids well. Human bodies between the reader/antenna can form an obstacle that prevents the tag from being read.
- Radiofrequency identification does not work through metals (problem with athermic windshields or armored vehicles).
- The waves are frequently reflected on the surface of objects (metal, concrete, the ground, etc.) and the presence of obstacles in the read field can influence the results.
- UHF technology can be directive and systems are installed according to the read zone of the antenna and its characteristics.
- A UHF tag can also have a direction linked to the polarization of its antenna. "Linear" tags are susceptible to their direction and are better read horizontally than vertically, for example.



1.3 Optimal orientation


In view of the above-mentioned factors, it is preferable to find the conditions of implementation that optimize system performance, i.e., the best possible position between the antenna and the tag.



The distances in the technical specifications of readers are measured facing the reader, with the tag parallel to the antenna.

An angle may be formed horizontally or vertically, depending on:

- the height of the antenna relative to the vehicle,
- the offset of the antenna on the side relative to the road..






1.4 Installations: the basic rules


It is advisable to position the antenna and to determine the detection zone **before** the barrier.

This will make detection more reliable and leave the system time to open the barrier.

Make sure there are no obstacles (barrier, totem, etc.) between the tag and the antenna.



Installing the antenna at height allows it to be directed downwards in order to limit the reading distance on the ground and to avoid the unwanted detection of a second vehicle.





1.5 Positioning the tags

The position of the hardened TeleTag® or the ETA v2* label on the windshield affects the performance and depends on the type of windshield.

*TeleTag®: UHF EPC1 GEN2 movable.



*ETA v2: destructible UHF EPC1 GEN2 adhesive tag





Goal: to position the tag for optimal quality/performance of reading.

Standard light vehicles

Put the tag at the top of the windshield, behind the central rear view mirror, and on the side where the reader antenna is, if possible. Position the tag so that it does not adhere to the upper edge of the windshield.



Choose the side according to the *position* of the antenna / reader

Heavy vehicles / trucks / buses

There are two solutions:

- a TeleTag® model (TLTA) interior tag or an ETA tag on the windshield. The rules for positioning the tag are the same as for light vehicles.
- an exterior tag for metal supports installed on the bodywork. Put the tag in a position where it is as parallel as possible to the reader antenna and in the required reading zone.



Installig the TeleTag®

Once you have chosen the position, install the tag using the support provided:

- Insert the tag using the method of your choosing:
 - o You can take the TeleTag® out of its support and keep it with you or install it on another vehicle.



- o The TeleTag® is permanently fixed.




- Fix the support horizontally to the windshield using the two-sided adhesive strips provided.

Caution: in view of the angle of certain windshields, remember to leave enough room to insert the tag in the support when choosing a position

1.6 Athermic windshields

Athermic windshields are made of sheets of metal in order to partially reduce the heat inside the vehicle's passenger compartment.

Athermic windshields can be recognized by the reflections on the glass.



Impact of athermic windshields on operation

Athermic windshields influence the performance of the system, because the metal blocks the radio waves. Most athermic windshields have a non-athermic section (see the non-exhaustive list in the Appendix). This section is intended for radio-based systems (GPS, toll payment badges, RFID, etc.). On the other hand, the reading distances may be shorter.

Therefore, it is important to take this parameter into consideration before installing and to proceed with tests in order to find the right position for the readers



2- SPECTRE range

ANT_SPECTRE-A/B



Antennas for SMA and SLA.

SMA



SPECTRE Access Module.
Possibility to connect up to four remote antennas.


SLA



SPECTRE Access Reader = SMA + ANT_UHF2.
Possibility to connect up to three remote antennas.



CAB_SPECTRE




The antenna cables are fitted with a module connector and an antenna connector (label on the antenna side of the cable).

Availables cables:

Length	Reference	Colored label on the cable
1.5 m	CAB-SPECTRE-1.5M	TECHNIWAVE PN: TWCA195-RPTNCF-RPTNCM-1.5M-1448
3 m	CAB-SPECTRE-3M	TECHNIWAVE PN: TWCA195-RPTNCF-RPTNCM-3M-1449
9 m	CAB-SPECTRE-9M	TECHNIWAVE PN: TWCA240-RPTNCF-RPTNCM-9M-1450
12 m	CAB-SPECTRE-12M	TECHNIWAVE PN: TWCA300-RPTNCF-RPTNCM-12M-1451

The cables can be serial-connected for intermediate lengths:



Length	Reference
3 m	CAB-SPECTRE-1.5M + CAB-SPECTRE-1.5M
4.50 m	CAB-SPECTRE-1.5M + CAB-SPECTRE-3M
6 m	CAB-SPECTRE-3M + CAB-SPECTRE-3M
10.5 m	CAB-SPECTRE-1,5M + CAB-SPECTRE-9M



ANT_SPECTRE-E/F



Antennas for ATX4.

ATX4



Module ATX4.
Possibility to connect up to four remote antennas.


ATX



ATX SPECTRE Access reader with integrated antenna.

CAB-ATEX


The CAB-ATEX includes a CAB-SPECTRE and an RP TNC adapter for connection to the GUB enclosure.



Available cables:

Length	Reference	Colored label on the cable
1.5 m	CAB-ATEX-1.5M	TECHNIWAVE PN: TWCA195-RPTNCF-RPTNCM-1.5M-1448
3 m	CAB-ATEX-3M	TECHNIWAVE PN: TWCA195-RPTNCF-RPTNCM-3M-1449
9 m	CAB-ATEX-9M	TECHNIWAVE PN: TWCA240-RPTNCF-RPTNCM-9M-1450
12 m	CAB-ATEX-12M	TECHNIWAVE PN: TWCA300-RPTNCF-RPTNCM-12M-1451

The cables can be serial-connected for intermediate lengths:



Length	Reference
3 m	CAB-SPECTRE-1.5M + CAB-ATEX-1.5M
4.50 m	CAB-SPECTRE-1.5M + CAB-ATEX-3M
6 m	CAB-SPECTRE-3M + CAB-ATEX-3M

3- Hybrid UHF SPECTRE and URx installation



3.1 Powers

The maximum power of the UHF readers must not be exceeded.


The power setting depends on the cables and antennas used.

In hybrid installations with a URx reader, the configuration of the reader must be modified with ULTRYS v1 to adapt the power to the new hardware and comply with the applicable regulations.


The drop-in power depends on the new cables used.

3.1.1 Table of URD powers

Modification of the power in ULTRYS v1: one single RF power field applies to the antennas.



1 lane / 1 antenna



1 lane / 2 antennas

	ETSI (R4x)	FCC (R5x)
URD + CAB_URD + ANT_URD (power by default)	31 dBm	30,5 dBm
URD + CAB_URD + ANT_SPECTRE	28 dBm	27,5 dBm
URD + CAB_SPECTRE + ANT_URD	31 dBm	30,5 dBm
URD + CAB_SPECTRE 1,5 or 3m + ANT_SPECTRE	31 dBm	30,5 dBm
URD + CAB_SPECTRE 9 or 12m + ANT_SPECTRE	29,7 dBm	29,3 dBm



3.1.2 Table of URC2 powers

Modification of the power in ULTRYS v1. One power field for the integrated antenna and one for the remote antenna.



Power of the integrated antenna

	ETSI (R4x)	FCC (R5x)
On the adhesive label on the reader		30 dBm







Power of remote antenna

	ETSI (R4x)	FCC (R5x)
URC2 + CAB_URD + ANT_URD (Puissance par défaut)	31 dBm	30,5 dBm
URC2 + CAB_URD + ANT_SPECTRE	28 dBm	27,5 dBm
URC2+ CAB_SPECTRE + ANT_URD	31 dBm	30,5 dBm
URC2 + CAB_SPECTRE 1,5 or 3m + ANT_SPECTRE	31 dBm	30,5 dBm
URC2 + CAB_SPECTRE 9 or 12m + ANT_SPECTRE	29,7 dBm	29,3 dBm

Modification of the power in ULTRYS v1. The power of the integrated antenna remains unchanged. Only the RF power of the remote antenna may have to be changed.





3.2 Details of the connector


Hardware / Type of connector			
<p>URD or URC2</p>  <p>Connector N female</p>	<p>CAB_URD</p>  <p>Connector N male</p>	<p>ANT_URD</p>  <p>Connector N female</p>	
<p>SMA</p>  <p>Connector RP TNC female</p>	<p>CAB_SPECTRE</p>  <p>Connector RP TNC male</p>	<p>ANT_SPECTRE</p>  <p>Connector RP TNC male</p>	
<p>ADAPT-URD-ANT2</p> <p>Connector N male</p>  <p>Connector RP TNC female</p>	<p>ADAPT-SMA-ANT-URD</p> <p>Connecteur RP TNC male</p>  <p>Connecteur N male</p>		
<p>ADAPT-SMA-CAB-URD</p> <p>Connector N female</p>  <p>Connector RP TNC male</p>	<p>ADAPT-CAB-URD-ANT2</p> <p>Connector N female</p>  <p>Connector RP TNC female</p>		




3.3 Hybrid system with a URD or URC2 reader




Initial installation			
			
or URC2	CAB_URD		

Replacement: ANT_URD by ANT_SPECTRE			
			
or URC2	CAB_URD	ADAPT-CAB-URD-ANT2	
Configuration with ULTRYS v1: no changes. No control of the antenna LED.			

Replacement: CAB_URD + ANT_URD by CAB_SPECTRE + ANT_SPECTRE			
			
or URC2	ADAPT-URD-ANT2	CAB_SPECTRE	
Configuration with ULTRYS v1: RF power setting (see table of powers). No control of the antenna LED.			

Ajout : ANT_SPECTRE + CAB_SPECTRE			
			
	CAB_URD		
or URC2			
	ADAPT-URD-ANT2	CAB_SPECTRE	
Configuration with ULTRYS v1: - Addition of the second antenna - RF power setting (see table of powers). No control of the antenna LED.			



Replacement: CAB_URD by CAB_SPECTRE				
 <p>or URC2</p>	 <p>ADAPT-URD-ANT2</p>	 <p>CAB_SPECTRE</p>	 <p>ADAPT-SMA-ANT-URD</p>	
<p>Configuration with ULTRYS v1: no changes.</p>				




3.4 Hybrid system with a SPECTRE reader

SMA + CAB_URD + ANT_URD			
	<p>ADAPT-SMA-CAB-URD</p>	<p>CAB_URD</p>	
Configuration with ULTRYS v2:			
<p>Step 3: Select SPECTRE reader</p>			
<p>Step 4: Select URD antenna</p>			
<p>Step 5: Select URD cables</p>			



SMA + CAB_URD + ANT_SPECTRE				
	 ADAPT- SMA- CAB -URD	 CAB_URD	 ADAPT- CAB- URD-ANT2	
Configuration with ULTRYS v2:				
Step 3: Select SPECTRE reader				
Step 4: Select SPECTRE antenna				
Step 5 : Select URD cables				

SMA + CAB_SPECTRE + ANT_URD



Configuration with ULTRYS v2:

Step 3: Select SPECTRE reader



Step 4: Select URD antenna



Step 5: Select the length of the SPECTRE cable






4- RSSI FILTERING

4.1 Introduction


RSSI, or “Received Signal Strength Indication”, is a measurement of the strength of the response received from the tag. The value sent by the reader is proportional to the amplitude of the received signal.

4.2 Exemple



Tags with an RSSI higher than -49dBm are sent to the system. The others are not.





When “Inversion” is activated, tags with an RSSI lower than -49dBm are sent to the system. The others are not.





5- Input / output parameters



5.1 Introduction

SPECTRE readers are fitted with four octo-coupled inputs (INx) and outputs (OUTx).

Therefore, the readers allow:

- the activation of the reading to be configured. For example, using a photoelectric barrier or a detection loop on the ground.
- an action to be taken at the reader outputs, for example by reading specific labels.

Their operation can be configured using the ULTRYS v2 software.



Refer to the ULTRYS v2 User Manual for more information.

5.2 Inputs

The reader checks the inputs every 50 ms. When an input is detected, the reader takes the configured action and continues to check the other inputs.

By applying a potential to IN_x that induces a minimum difference in potential of 3.3 Vdc between IN_x and V^{+opt} ($V^{+opt} - V_{IN} > 3,3 \text{ V}$), the transistor turns on (switch closed), and the information indicating the presence of a signal at the input is transmitted to the reader. If no potential is applied to the IN input, the transistor is blocked (switch open).

Caution: the polarization voltage V⁺ depends on the voltage available on the IN of the external system.

For activation: $3.3 \text{ Vdc} \leq V^{+opt} - V_{IN} \leq 36 \text{ Vdc}$.

<p>IN input active</p>	
<p>IN input inactive</p>	
<p>Connection</p>	



5.3 Examples of input use

5.3.1 Reading activated when the presence of a vehicle is detected with detector OPTEX

Vehicle presence detector




DETECT-VEHICLE-01

The OPTEX presence detector is designed to reliably detect the presence of a vehicle when it is stopped or moving at up to 20 km/h.

Combining microwave detection and ultrasonic sensor, it offers 5 levels of sensitivity adjustment. This accessory connects easily to the SPECTRE reader, allowing to activate the tag reading during the passage of the vehicle.



ULTRYS v2 settings





Conection

OPTEX terminal block




Operation

When a vehicle is detected by the OPTEX detector, the detector relay switches to "closed", the information is sent to the reader via the INx input of the corresponding channel (in the example channel 1). The reader will start reading on this channel as long as the input is active.




5.3.2 Reading activated when the presence of a vehicle is detected with ground loop

ULTRYS v2 settings



Connection



Operation

When the ground loop detects a vehicle, the information is sent to the reader through the IN input of the corresponding channel (channel 1 in this example). The reader reads on this channel for as long as the input is active.



5.4 Outputs

The outputs OUT_x behave like open/closed switches. The rest state is configured using the ULTRYS v2 software. A normally open output will be closed by the action of the reader and vice versa (refer to the ULTRYS v2 User Manual).

Depending on the chosen option, the output will be connected to an internal pull-up (pull-up to V+) or left unconnected (collector open).

In both cases, the polarization potentials V+_{opt} and V-_{opt} must be connected.

Caution: DO NOT CONNECT DIRECTLY THE OUT_x OUTPUTS TO V+_{OPT}

5.4.1 PULL UP TO V+

ULTRYS v2 settings
Pull up to V+

Connection
Pull up à V+


The operating diagram is given for outputs configured as Normally Open in ULTRYS v2.

The system is represented by a LED for better understanding, the value of the Ruser resistor is to be determined according to the client "system" connected.

Caution: I_{OUT} max 200mA


Operating diagram

No tag detected:



OUT is pull up to V+opt: Vout = V+opt
LED OFF

Tag detected:




OUT is pull up to V- opt: Vout = V- opt
LED ON

Note: RDSon max = 2Ω, the maximum residual voltage is therefore 0.4Volts.


5.4.2 Open drain

If the system is not compatible with the V+opt voltage used by the pull up, use the open drain setting and bring a voltage that we will call Vsystem.



ULTRYS v2
Settings
Open drain



Connection
Open drain





<p>Operating diagram 1: Without pull up to Vsystem</p>	<p>The operating diagram is given for outputs configured as Normally Open in ULTRYs v2.</p> <p>Caution: I_{OUT} max 200mA</p>	
	<p>No tag detected:</p> 	<p>OUT is not connected The system is not powered</p>
<p>Tag detected:</p> 	<p>OUT is pull up to V-opt: V_{out} = V-opt The system is powered</p> <p>Note: RDSon max = 2Ω, the maximum residual voltage is therefore 0.4Volts.</p>	




Operating diagram 2:
With pull up to Vsystem

The operating diagram is given for outputs configured as Normally Open in ULTRYS v2.


Caution: I_{OUT} max 200mA

No tag detected:



OUT is pull up to Vsystem
The system is not powered

Tag detected:





OUT is pull up to V-opt: V_{out} = V-opt
The system is powered

Note: R_{DSon} max = 2Ω, the maximum residual voltage is therefore 0.4Volts..

5.5 Examples of output use


5.5.1 Activation of an external optical warning

ULTRYS v2 settings



Connection

In this example, the optical warning operates at 24 Vdc.





Operation

The reader reads continuously. When the reader sends a tag to the system on channel 1, the state of output 1 changes for 200 ms and returns to its normally open default position in this example.




5.5.2 Control of an external relay

ULTRYS v2 settings



Connection



Operation

The reader reads continuously.

When the reader sends a tag to the system on channel 1, the OUT_1 is pull up to $V+_{opt}$, the relay is piloted. When there is no tag, the relay is not piloted.



6- Approach to projects

A number of steps must be followed when equipping a site with a SPECTRE Access configuration.

Site analysis

Collect the basic information required to define the configuration to be installed:

- Site map,
- Direction of the traffic flows,
- Dimensions,
- Types of vehicles to be identified.

Definition of the targets

Identification zones: choose the point where the vehicles are to be identified:

- Positions,
- Dimensions.

Choice of hardware

On the basis of the targets and restrictions identified in the preceding steps, the first hardware choices can be made (type of reader, number of readers, type of tag, etc.).

The technical options are determined by the constraints. This analysis produces a clear vision of the feasibility of the preferred configuration and any arrangements or compromises that may be necessary.

Definition of the tests

It is advisable to define the tests required to validate the configuration with the customer, if necessary, right from the outset. Make sure that representative vehicles (vehicles with athermic and non-athermic windshields) and the equipment required for the purposes of the validation are available.



7- Examples of configurations

Some conventional vehicle access configurations are described below, with an indication of the typical positions of the antennas/readers.


These configurations are just examples. They are generic and intended to provide food for thought.

Certain functional factors may be influenced by external parameters.

7.1 One-lane single access



- An SLA reader is installed on the side.
- It is positioned before the barrier so that vehicles can be detected early enough.





7.2 One-lane single access – Double height

When a single antenna is not sufficient to cover the entire height required to identify light vehicles and heavy goods vehicles.




SPECTRE

2 ANTENNAS CONFIGURATION



- One SLA reader and one SPECTRE antenna installed on the side.
- One 1.5m cable to connect the external antenna to the SLA reader.
- One antenna optimally positioned to detect light vehicles.
- One antenna optimally positioned to detect heavy goods vehicles.
- The reader is placed in front of the barrier in order to detect vehicles at a sufficient distance before the barrier.
- Both antennas are controlled by the same reader to avoid any risks of interference.






7.3 Single Entrance / Exit for light vehicles only with a central island




- One SLA reader and one SPECTRE antenna installed on the central island.
- One antenna cable to connect the external antenna to the SLA reader.
- One antenna installed to detect vehicles at the entrance.
- One antenna installed to detect vehicles at the exit.
- Each antenna monitors one lane and sends the data to its own specific reader output.
- The reader is placed in front of the barrier in order to detect vehicles at a sufficient distance before the barrier. This also limits the number of unwanted readings on another lane.
- Both antennas are controlled by the same reader to avoid any risks of interference.



7.4 Double-width access on a two-way public road

Vehicles can arrive from both sides / sliding gate.




- SLA reader with a remote antenna, if an antenna cable can be routed.
- One antenna on each side of the gate in order to be in the axis of arriving vehicles.
- **Pay close attention to the width in order to remain in a zone covered by the reader.**





7.5 Multiple-lane access

One SMA reader with four remote antennas.



- The antennas are controlled by the same reader to avoid any risks of interference.
- Each antenna monitors one lane and sends the data to an independent output.
- The antennas can be installed up to 12m from the module, which is positioned in the center.

Installation configuration

	Lane 1	Lane 2	Lane 3	Lane 4
Antenna				
Ant 1	On back of reader	6 m cable (2 x 3 m)	1.5 m cable	6 m cable (2 x 3 m)
Remove a lane	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>



8- Installation methodology


- Position the tag inside the vehicle. **Do not hold the tag in your hand when validating**
- Put the vehicle in the typical / preferred identification zone.
- Adjust the height and direction of the antenna until a reading is obtained.
- Test the configuration with the vehicle in motion.
- Adjust the antenna until it produces an optimal result.

This configuration is optimized for the test vehicle. Ideally, these settings must also be configured using a vehicle that is very different from the first one (higher windshield, LCV, etc.) in order to install the antenna in a position covering as many use cases as possible.




9- Athermic windshields

Type A




verre teinté (non athermique)

Type B




verre athermique épargne

Type C




verre athermique

Type D




verre athermique

Type E




verre athermique

Type F




verre athermique de couleur neutre épargne

Type G




verre athermique

Type H




verre athermique

Type I




verre athermique

Type J




verre athermique (sans épargne) verre athermique de couleur dégradée

Type K



verre athermique (sans épargne)

Type L




verre athermique de couleur neutre verre chauffant




10- Radiation pattern ANT-SPECTRE

10-1 Lower band – Horizontal polarization; 867 MHz






10-2 Lower band – Vertical polarization; 867 MHz






10-3 Upper band - Horizontal polarization; 915 MHz






10-4 Upper band - Vertical polarization; 915 MHz






11- Radiation pattern integrated antenna ATX

11-1 Lower band – Horizontal polarization; 867 MHz






11-2 Lower band – Vertical polarization; 867 MHz






11-3 Upper band - Horizontal polarization; 915 MHz





11-4 Upper band - Vertical polarization; 915 MHz





12- FAQ

Question	Cause	Recommendation
The red LED on the SMA flashes.	Power supply problem.	Check: <ul style="list-style-type: none"> - The maximum current supplied by the power supply. - The supply voltage in the reader. - the type of cable - the distance between the power supply and the reader.
My reader does not start up.	Insufficient voltage. Incorrect wiring.	Check the voltage at the terminals of the reader. Use a regulated power supply.
The red LED on the SMA flashes three times after every RF scan sequence.	RF connection problem with one or more cables and/or antennas.	Check: <ul style="list-style-type: none"> - the connections of the antenna cables. - the condition of the antenna cables.
The red LED on the SMA flashes five times after every RF scan sequence.	System temperature too high.	Install the SMA module in the shade.
No reading on one of the antennas, even over short distances.	Incorrect configuration of the channels.	Check the configuration (ground loop, EPC or RSSI filter) and the connections of the antennas to the channels.
My tag cannot be identified due to an athermic windshield.	The non-athermic section is incorrectly positioned or the reader is too far from the vehicle.	Position the tag correctly in the non-athermic section or change the position of the reader.
The vehicle does not have a non-athermic section.		Change the position or the type of the tag.



13- VERSION

Date	Version	Description
11/04/2019	1.0	<i>New document.</i>
18/06/2019	2.0	<i>Addition of input / output management // Migration between the two ranges</i>
28/07/2020	3.0	<i>Addition ATX // VIK OPTEX captor // IN OUT diagram modified</i>

Headquarters / EMEA

13850 Gréasque, France
Tel.: +33 (0)4 42 12 60 60

PARIS-IDF Office

92290 Châtenay-Malabry, France
Tel.: +33 (0)1 43 50 11 43

STid UK Ltd. LONDON

Hayes UB11 1FW, UK
Tel.: +44 (0) 192 621 7884

STid UK Ltd.

Gallows Hill, Warwick CV34 6UW, UK
Tel.: +44 (0) 192 621 7884

NORTH AMERICA Office

Irving, Texas 75063-2670, USA
Tel.: +1 469 524 3442

LATINO AMERICA Office

Cuahtémoc 06600 CDMX, México
Tel.: +521 (55) 5256 4706



info@stid.com

www.stid-security.com